

Vehicle Type	FULL-SIZE VANS											COMPACT VANS					OTHER		
	Low-roof						Mid-/High-roof					Ford Transit Connect	Chevrolet City Express	Ram Promaster City	Mercedes Metris	Nissan NV200	KUV Service Bodies	Box Trucks	Trailers
	Ford Transit 130" WB	Ford Transit 148" WB	Ford E-Series	Chevrolet Express	GMC Savana	Nissan NV	Ford Transit 130" WB	Ford Transit 148" WB	RAM ProMaster (All Heights)	Sprinter	Nissan NV								
Model Years	2015 & Later	2015 & Later	1992-2013	1996 & Later	1996 & Later	2011 & Later	2015 & Later	2015 & Later	2014 & Later	2007 & Later	2011 & Later	2010 & Later	2016 & Later	2015 & Later	2016 & Later	2014 & Later			
Mandatory Mounting Kits for EZGLIDE2™ Drop-Down Ladder Racks																			
2085-0-01											X	X	X	X	X				
2130-0-01 ¹	X ¹						X ¹												
2102-0-01		X						X											
2113-0-01						X				X ²								X	X
2115-0-01									X										
2505																		X	
EZGLIDE2™ Drop-Down Ladder Racks																			
2261-3-01												X	X	X	X	X			
2265-3-01												X	X	X	X	X			
2267-3-01												X	X	X	X	X			
2271-3-01	X	X	X	X	X	X													
2275-3-01	X	X	X	X	X	X													
2277-3-01	X	X	X	X	X	X													
2291-3-01							X	X	X	X	X							X ⁴	X ⁴
2295-3-01							X	X	X	X	X						X ³	X ⁴	X ⁴
2297-3-01							X	X	X	X	X							X ⁴	X ⁴
Mounting Kits for Quick Clamp and All-Purpose Racks R=Recommended X=Mandatory																			
2085-0-01											X	R	R	R	R	R			
2130-0-01 ¹	R ¹						R ¹												
2102-0-01		R						R											
2113-0-01						X				X ²								R	R
2115-0-01									X										
ALUMINUM QUICK CLAMP RACKS																			
223-3-03												X	X	X	X	X			
224-3-03												X	X	X	X	X			
225-3-03												X	X	X	X	X			
233-3-03	X	X	X	X	X	X													X ⁴
234-3-03	X	X	X	X	X	X													X ⁴
236-3-03	X	X	X	X	X	X													X ⁴
ALUMINUM ALL-PURPOSE RACKS																			
209-3-03	X	X	X	X	X	X	X	X	X ⁵	X	X							X	X
2097-3-03	X	X	X	X	X	X	X	X	X ⁵	X	X							X	X
218-3-03												X	X	X	X	X			
222-3-03												X	X	X	X	X			
STEEL ALL-PURPOSE RACKS																			
205-3	205-5		X	X	X														
216-3	216-5		X	X	X														
2056-3	2056-5		X	X	X														
210-3			X	X	X														

¹ This mounting kit will be available starting July, 2017. Until then, the 2102-0-01 can be substituted. See Product Update Bulletin 16-0008.

² If the Sprinter van has factory installed roof mounting rails, this kit is not necessary.

³ Order a 70521 handle kit with each 2295-0-01 dropdown used.

⁴ As there are many different styles of trailers, check for adequate rack clearances.

⁵ Not recommended for 159" wheelbase or 159" extended wheelbase Promaster vans.

